

## HX-RGB4-RF20K

### RF 20 key LED RGB Controller

Controller adopts the advanced micro control unit, it is used for controlling a variety of LED light. For instance, point source of light, flexible light strip, wall washer lamp and so on. It has many advantages such as good appearance, easy connection and simplicity to use. Adopts RF 20 key remote control to ON/OFF, choose colors, change dynamic modes.



### Product Features:

- Designed for RGB constant voltage LED lights, Max.output:3\*6.6A.
- Working voltage DC12-24V, it can be universal in this range.
- Adopts PWM digital technology, signal frequency: 107Hz.
- RF 20-key wireless remote, RF frequency: 433.92MHz.
- 14 modes in total, including 8 static colors and 6 dynamic changes.
- Warranty of this product is 3 year, exclude the artificial situation of damaged or overload working.

## Technical Parameters

### Controller

<b>Working temperature</b>	-20-60°C	<b>Supply voltage</b>	DC12V-24V
<b>Static power consumption</b>	<1W	<b>Connecting mode</b>	common anode
<b>Grayscale</b>	64 levels (RGB each)	<b>Speed stage</b>	100 grade
<b>External dimension</b>	L80×W64×H24mm	<b>Packing size</b>	L106×W64×H56 mm
<b>Net weight</b>	95g	<b>Gross weight</b>	115g
<b>Output</b>	3 channels	<b>Output current</b>	≤6.6A(each channel)
<b>Mode</b>	14	<b>Remote distance</b>	Up to 20M
<b>RF frequency</b>	433.92Mhz	<b>Memory function</b>	support
<b>Max. Output power</b>	12V:<240W, 24V:<480W		

### Remote control

<b>Working temperature</b>	-20°C~60°C	<b>Supply voltage</b>	DC3V (CR2025)
<b>Standby current</b>	<3.3uA	<b>Working current</b>	<12mA
<b>Standby power</b>	9.9uW	<b>Working power</b>	36mW
<b>Net weight</b>	24g	<b>RF frequency</b>	433.92MHz
<b>External dimension</b>	L85*W51*H6 mm	<b>RF distance</b>	≤20m

## Interface Specifications



## Direction for use

- Connect the load wire and sync-signal cable at first, following by the power wire.
- Ensure short circuit can not occur before you turn on the power.
- Adopt RF wireless remote control, 20 keys in total, function of each button as below :



<b>Brightness +</b>	Brightness -	pause	on/off
<b>Static red</b>	Static green	Static blue	Static white
<b>Static orange</b>	Static yellow	Static cyan	Static purple
<b>Auto run</b>	three base color jumpy	Three color gradually change	speed +
<b>Flash</b>	seven base color jumpy	Seven color gradually change	speed-

## RF CODE

Receiver can be controlled by any one the same remote as factory default; remote control delivered with unique RF code as factory default; if unique-control is needed, please matching the code before installation and using.

### Matching code operation

Receiver and Remote Control are coded as default, matching them before using, if unique-control or new-coded-remote is needed, pairing the remote and the receiver as below operation instruction before using:

- Step 1:** Pressing key “FLASH” and hold on, power on the controller, the load LEDs will be 50% brightness white as responding.
- Step 2:** Pressing “FLASH” 3times in 3 seconds, corresponding to the operation, the LED’s brightness will change as 25%-10%-back to preset level.
- Code learning successfully, the receiver only can be controlled by the remote.
- If not, please re-operate from step 1 to 2.

### Clear code operation

Back to factory default, wall-panel can be controlled by any one the same remote control.

- Step 1:** Pressing key “JUMP7” and hold on, power on the controller, the load LEDs will be 50% brightness white as responding.

2. **Step 2:** Pressing “JUMP7” 3times in 3 seconds, corresponding to the operation, the LED’s brightness will change as 25%-10%-back to preset level.
3. Code clearing successfully, the LEDs will be back to the status before the power off, and the receiver can be controlled by any remote control (any one the same remote control can be used to clear the code).
4. If not, please re-operate from step 1 to 2.

## Typical Applications

